

Professional manufacturer, best quality with competitive price • Recommended by the world UT NDT inspection association for training and examination • Core technology with independent intellectual property rights, certificate of CE, GOST and etc.. •

Film Auto-Dry Machine



Overview

MITECH Film auto-dry machine MD-500 is mainly used to quickly dry the film after ray detection. It adopts PU roller and soft rubber roller to convey film. Together with good water absorption sponge shaft, it can quickly and efficiently dry the film without water and damage. Multi-functional as it is, the spinning speed is adjustable and thus makes it convenient to operate. The film can be washed again by external water source or inner water sink. The circulation pump makes it possible to supply clean water when necessary. In a word, MD-500 is the necessary equipment for ray detection.

Technical Parameters

Film size
Film processing speed
Drug area
Supplement
Drying temperature
Water temperature
Water Consumption
Power supply
Weight
Dimensions

10*10 cm~ 35cm	
450 - 125 cm/m, Stepless speed change	
5.0 L (External expand available)	
Auto	
20-60°C (adjustable)	
5°C-30°C	
0.2 L/m (while running)	
220-240V 5A 50-60Hz	
20KG(empty) 25KG(water full)	
405mm*600mm*430mm	

Process Flow





 \rightarrow

Dry out the film

The film to be taken